

Engineering Data
HFUC-2UH Units



Harmonic
Drive AG



QUICKLINK
www.harmonicdrive.de/2050

...just move it!

Contents

1.	General	04
1.1	Description of Safety Alert Symbols	05
1.2	Disclaimer and Copyright	05
2.	Safety and Installation Instructions	06
2.1	Hazards	06
2.2	Intended Purpose	07
2.3	Non Intended Purpose.....	07
2.4	Declaration of Conformity.....	08
3.	Technical Description	09
3.1	Product Description	09
3.2	Ordering code	09
3.3	Technical Data.....	10
3.3.1	General Technical Data.....	10
3.3.2	Dimensions.....	11
3.3.3	Minimum Housing Clearance.....	16
3.3.4	Accuracy.....	16
3.3.5	Torsional Stiffness	16
3.3.6	Bearings.....	17
3.3.7	Materials Used	18
4.	Driving Arrangements	19
4.1	Selecting Harmonic Drive® Gears.....	21
4.1.1	Torque Based Dimensioning.....	22
4.1.2	Life of the Wave Generator Bearing.....	24
4.1.3	Stiffness Based Dimensioning	25
4.2	Calculation of the Torsion Angle.....	27
4.3	Accuracy of the Oldham Coupling.....	27
4.4	Efficiency Versus Load	28
4.4.1	Efficiency Calculations	28
4.4.2	Efficiency Tables.....	29
4.5	Free Load Torques	31
4.5.1	No Load Running Torque	31
4.5.2	No Load Starting Torque.....	32
4.5.3	No Load Back Driving Torque.....	32
4.6	Life for Continuous Operation	33
4.6.1	Output Bearing for Oscillating Motion.....	35
4.7	Permissible Static Tilting Moment.....	36
4.8	Angle of Inclination	36
4.9	Lubrication	37
4.9.1	Grease Lubrication	37
4.9.2	Oil Lubrication	39
4.10	Axial Forces at the Wave Generator	40

5.	Installation and Operation	41
5.1	Transport and Storage.....	41
5.2	Gear Condition at Delivery.....	41
5.3	Assembly Information.....	41
5.4	Recommended Tolerances for Assembly	42
5.5	Lubrication	42
	5.5.1 Grease Lubrication	42
	5.5.2 Amount of Grease.....	43
	5.5.3 Additional Grease Package	44
	5.5.4 Grease Change.....	45
	5.5.5 Oil Lubrication	45
5.6	Assembly.....	46
5.7	Mounting.....	47
	5.7.1 Motor Assembly	47
	5.7.2 Wave Generator Components	49
	5.7.3 Mounting the Wave Generator (WG) to the Motor Shaft.....	51
	5.7.4 Check before Assembly of the Wave Generator (WG)	51
	5.7.5 Assembly Control.....	52
	5.7.6 Assembly of the Output Flange	53
	5.7.7 Assembly of the Housing Flange	53
6.	Glossary.....	54
6.1	Technical Data.....	54
6.2	Labelling, Guidelines and Regulations	60

1. General

About this documentation

This document contains safety instructions, technical data and operation rules for products of Harmonic Drive AG. The documentation is aimed at planners, project engineers, commissioning engineers and machine manufacturers, offering support during selection and calculation of the servo actuators, servo motors and accessories.

Rules for storage

Please keep this document for the entire life of the product, up to its disposal. Please hand over the documentation when re-selling the product.

Additional documentation

For the configuration of drive systems using the products of Harmonic Drive AG, you may require additional documents. Documentation is provided for all products offered by Harmonic Drive AG and can be found in pdf format on the website.

www.harmonicdrive.de

Third-party systems

Documentation for parts supplied by third party suppliers, associated with Harmonic Drive® components, is not included in our standard documentation and should be requested directly from the manufacturers.

Before commissioning products from Harmonic Drive AG with servo drives, we advise you to obtain the relevant documents for each device.

Your feedback

Your experiences are important to us. Please send suggestions and comments about the products and documentation to:

Harmonic Drive AG
Marketing and Communications
Hoenbergstraße 14
65555 Limburg / Lahn
Germany
E-Mail: info@harmonicdrive.de

1.1 Description of Safety Alert Symbols

Symbol	Meaning
	Indicates an imminent hazardous situation. If this is not avoided, death or serious injury could occur.
	Indicates a possible hazard. Care should be taken or death or serious injury may result.
	Indicates a possible hazard. Care should be taken or slight or minor injury may result.
	Describes a possibly harmful situation. Care should be taken to avoid damage to the system and surroundings.
	This is not a safety symbol. This symbol indicates important information.
	Warning of a general hazard. The type of hazard is determined by the specific warning text.
	Warning of dangerous electrical voltage and its effects.
	Beware of hot surfaces.
	Beware of suspended loads.
	Precautions when handling electrostatic sensitive components.

1.2 Disclaimer and Copyright

The contents, images and graphics contained in this document are protected by copyright. In addition to the copyright, logos, fonts, company and product names can also be protected by brand law or trademark law. The use of text, extracts or graphics requires the permission of the publisher or rights holder.

We have checked the contents of this document. Since errors cannot be ruled out entirely, we do not accept liability for mistakes which may have occurred. Notification of any mistake or suggestions for improvements will be gratefully received and any necessary correction will be included in subsequent editions.

2. Safety and Installation Instructions

Please take note of the information and instructions in this document. Specially designed models may differ in technical detail. If in doubt, we strongly recommend that you contact the manufacturer, giving the type designation and serial number for clarification.

2.1 Hazards



DANGER

Electric products have dangerous live and rotating parts. All work during connection, operation, repair and disposal must be carried out by qualified personnel as described in the standards EN50110-1 and IEC 60364! Before starting any work, and especially before opening covers, the actuator must be properly isolated. In addition to the main circuits, the user also has to pay attention to any auxiliary circuits.

Observing the five safety rules:

- Disconnect mains
- Prevent reconnection
- Test for absence of harmful voltages
- Ground and short circuit
- Cover or close off nearby live parts

The measures taken above must only be withdrawn when the work has been completed and the device is fully assembled. Improper handling can cause damage to persons and property. The respective national, local and factory specific regulations must be adhered to.



DANGER

Electric, magnetic and electromagnetic fields are dangerous, in particular for persons with pacemakers, implants or similar. Vulnerable groups must not be in the immediate vicinity of the products themselves.



DANGER

Built-in holding brakes alone are not functionally safe. Particularly with unsupported vertical axes, the functional safety and security can only be achieved with additional, external mechanical brakes.



WARNING

The successful and safe operation of gears, products requires proper transport, storage and assembly as well as correct operation and maintenance.



ATTENTION

The surface temperature of gears, motors and actuators can exceed 55 degrees Celsius. The hot surfaces should not be touched.



ADVICE

Movement and lifting of products with a mass > 20 Kg should only be carried out with suitable lifting gear.

ADVICE

Cables must not come into direct contact with hot surfaces.

INFORMATION

Special versions of drive systems and motors may have differing specifications. Please consider all data sheet, catalogues and offers etc. sent concerning these special versions.

2.2 Intended Purpose

The Harmonic Drive® products are intended for industrial or commercial applications. They comply with the relevant parts of the harmonised EN 60034 standards series.

Typical areas of application are robotics and handling, machine tools, packaging and food machines and similar machines.

The products may only be operated within the operating ranges and environmental conditions shown in the documentation (altitude, degree of protection, temperature range etc).

Before plant and machinery which have Harmonic Drive® products built into them are commissioned, the compliance must be established with the Machinery Directive, Low Voltage Directive and EMC guidelines.

Plant and machinery with inverter driven motors must satisfy the protection requirements in the EMC guidelines. It is the responsibility of the installer to ensure that installation is undertaken correctly.

Signal and power lines must be shielded. The EMC instructions from the inverter manufacturer must be observed in order that installation meets the EMC regulations.

2.3 Non Intended Purpose

The use of products outside the areas of application mentioned above or, inter alia, other than in the operating areas or environmental conditions described in the documentation is considered as non-intended purpose.

ADVICE

The following areas of application are, inter alia, those considered as non-intended purpose:

- Aerospace
- Areas at risk of explosion
- Machines specially constructed or used for a nuclear purpose whose breakdown might lead to the emission of radio-activity
- Vacuum
- Machines for domestic use
- Medical equipment which comes into direct contact with the human body
- Machines or equipment for transporting or lifting people
- Special devices for use in annual markets or leisure parks

2.4 Declaration of Conformity

Harmonic Drive® gears are components for installation in machines as defined by the machine directive 2006/42/EG .
Commissioning is prohibited until such time as the end product has been proved to conform to the provisions of this directive.

Essential health and safety requirements were considered in the design and manufacture of these gear component sets.
This simplifies the implementation of the machinery directive by the end user for the machinery or the partly completed machinery. Commissioning of the machine or partly completed machine is prohibited until the final product conforms to the EC Machinery Directive.

3. Technical Description

3.1 Product Description

The Standard Series

HFUC-2UH Series Units are available in thirteen sizes with gear ratios of 30, 50, 80, 100, 120 and 160:1 offering repeatable peak torques from 9 to 9180 Nm. The output bearing with high tilting rigidity enables the direct introduction of high payloads without further support and thus permits simple and space saving design installations.

If required, the Units are available as specific configurations tailored to your application and can utilise standard servo motors. Unit and motor together form a compact and lightweight system capable of withstanding high loads. On request, the series is available for ambient temperatures between -40 and 90 °C and can be used with a large selection of special lubricants tailored to your application. Due to the Units positioning accuracy, stable machine characteristics with short cycle times are guaranteed.

3.2 Ordering Code

Table 9.1

Series	Size	Ratio ²⁾						Version	Special design
		30	50	80	100	120	160		
HFUC	14	30	50	80	100			2UH	According to customer requirements
	17	30	50	80	100	120			
	20	30	50	80	100	120	160		
	25	30	50	80	100	120	160		
	32	30	50	80	100	120	160		
	40		50	80	100	120	160		
	45		50	80	100	120	160		
	50		50	80	100	120	160		
	58		50	80	100	120	160		
	65		50	80	100	120	160		
	80		50	80	100	120	160		
	90		50	80	100	120	160		
	100 ¹⁾		50	80	100	120	160		
Ordering code									
HFUC	-	25	-	100	-	2UH	-	SP	

¹⁾ On request

²⁾ The ratios shown here are for a standard driving configuration with the circular spline fixed, the Wave Generator used for the input and the Flexspline attached to the output. Other configurations are possible. Please consult chapter 4 "Ratio".

Table 9.2

Version	
Ordering code	Description
2UH	Unit with integrated cross roller output

Clarification of the technical data can be found in the Glossary

3.3 Technical Data

3.3.1 General Technical Data

Table 10.1

	Unit	HFUC-14-2UH				HFUC-17-2UH				
		30	50	80	100	30	50	80	100	120
Ratio	i []	30	50	80	100	30	50	80	100	120
Repeatable peak torque	T_R [Nm]	9.0	18	23	28	16	34	43	54	54
Average torque	T_A [Nm]	6.8	6.9	11	11	12	26	27	39	39
Rated torque	T_N [Nm]	4.0	5.4	7.8	7.8	8.8	16	22	24	24
Momentary peak torque	T_M [Nm]	17	35	47	54	30	70	87	110	86
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	14000				10000				
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	8500				7300				
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	6500				6500				
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	3500				3500				
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	0.033				0.079				
Weight	m [kg]	0.49				0.64				

Table 10.2

	Unit	HFUC-20-2UH						HFUC-25-2UH					
		30	50	80	100	120	160	30	50	80	100	120	160
Ratio	i []	30	50	80	100	120	160	30	50	80	100	120	160
Repeatable peak torque	T_R [Nm]	27	56	74	82	87	92	50	98	137	157	167	176
Average torque	T_A [Nm]	20	34	47	49	49	49	38	55	87	108	108	108
Rated torque	T_N [Nm]	15	25	34	40	40	40	27	39	63	67	67	67
Momentary peak torque	T_M [Nm]	50	98	127	147	147	147	95	186	255	284	304	314
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	10000						7500					
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	6500						5600					
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	6500						5600					
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	3500						3500					
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	0.193						0.413					
Weight	m [kg]	0.98						1.5					

3.3.2 Dimensions

Illustration 11.1

HFUC-14-2UH [mm]




Illustration 11.2

HFUC-17-2UH [mm]




Illustration 11.3

HFUC-20-2UH [mm]




Illustration 11.4

HFUC-25-2UH [mm]




Table 12.1

	Unit	HFUC-32-2UH						HFUC-40-2UH				
		30	50	80	100	120	160	50	80	100	120	160
Ratio	i []	30	50	80	100	120	160	50	80	100	120	160
Repeatable peak torque	T_R [Nm]	100	216	304	333	353	372	402	519	568	617	647
Average torque	T_A [Nm]	75	108	167	216	216	216	196	284	372	451	451
Rated torque	T_N [Nm]	54	76	118	137	137	137	137	206	265	294	294
Momentary peak torque	T_M [Nm]	200	382	568	647	686	686	686	980	1080	1180	1180
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	7000						5600				
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	4800						4000				
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	4600						3600				
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	3500						3000				
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	1.69						4.50				
Weight	m [kg]	3.2						5.0				

Table 12.2

	Unit	HFUC-45-2UH					HFUC-50-2UH				
		50	80	100	120	160	50 ¹⁾	80	100	120	160
Ratio	i []	50	80	100	120	160	50 ¹⁾	80	100	120	160
Repeatable peak torque	T_R [Nm]	500	706	755	823	882	715	941	980	1080	1180
Average torque	T_A [Nm]	265	390	500	620	630	350	519	666	813	843
Rated torque	T_N [Nm]	176	313	353	402	402	245	372	470	529	529
Momentary peak torque	T_M [Nm]	950	1270	1570	1760	1910	1430	1860	2060	2060	2450
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	5000					4500				
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	3800					3500				
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	3300					3000				
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	3000					2500				
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	8.68					12.6				
Weight	m [kg]	7.0					8.9				

¹⁾ Only valid with oil lubrication. Grease lubrication can be used when the average torque T_{av} is not greater than half the nominal torque T_N

Illustration 13.1

HFUC-32-2UH [mm]




Illustration 13.2

HFUC-40-2UH [mm]




Illustration 13.3

HFUC-45-2UH [mm]




Illustration 13.4

HFUC-50-2UH [mm]




Table 14.1

	Unit	HFUC-58-2UH					HFUC-65-2UH				
Ratio	i []	50 ¹⁾	80	100	120	160	50 ¹⁾	80	100	120	160
Repeatable peak torque	T_R [Nm]	1020	1480	1590	1720	1840	1420	2110	2300	2510	2630
Average torque	T_A [Nm]	520	770	1060	1190	1210	720	1040	1520	1570	1570
Rated torque	T_N [Nm]	353	549	696	745	745	490	745	951	951	951
Momentary peak torque	T_M [Nm]	1960	2450	3180	3330	3430	2830	3720	4750	4750	4750
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	4000					3500				
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	3000					2800				
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	2700					2400				
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	2200					2200				
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	27.3					46.8				
Weight	m [kg]	14.6					20.9				

Table 14.2

	Unit	HFUC-80-2UH					HFUC-90-2UH				
Ratio	i []	50 ¹⁾	80	100	120	160	50 ¹⁾	80	100	120	160
Repeatable peak torque	T_R [Nm]	2440	3430	4220	4590	4910	3530	3990	5680	6160	6840
Average torque	T_A [Nm]	1260	1830	2360	3130	3130	1720	2510	3360	4300	4300
Rated torque	T_N [Nm]	872	1320	1700	1990	1990	1180	1550	2270	2570	2700
Momentary peak torque	T_M [Nm]	4870	6590	7910	7910	7910	6660	7250	9020	9800	11300
Maximum input speed (oil lubrication)	$n_{in(max)}$ [rpm]	2900					2700				
Maximum input speed (grease lubrication)	$n_{in(max)}$ [rpm]	2300					2000				
Average input speed (oil lubrication)	$n_{av(max)}$ [rpm]	2300					2100				
Average input speed (grease lubrication)	$n_{av(max)}$ [rpm]	1500					1300				
Moment of inertia	J_{in} [$\times 10^{-4}$ kgm ²]	122					214				
Weight	m [kg]	30.8					42.5				

¹⁾ Only valid with oil lubrication. Grease lubrication can be used when the average torque T_{av} is not greater than half the nominal torque T_N

Illustration 15.1

HFUC-58-2UH [mm]




Illustration 15.2

HFUC-65-2UH [mm]




Illustration 15.3

HFUC-80-2UH [mm]





Illustration 15.4

HFUC-90-2UH [mm]




3.3.3 Minimum Housing Clearance

Table 16.1

[mm]

Size	8	11	14	17	20	25	32	40	45	50	58	65	80	90
X	6.0	7.0	6.0	4.5	3.5	4.0	3.5	4.0	3.5	3.0	5.0	4.0	4.0	3.0
ØZ	21.5	30	38	45	53	66	86	106	119	133	154	172	212	239

Illustration 16.2



3.3.4 Accuracy

Table 16.3

[arcmin]

Size	14		17		≥ 20	
	Ratio	30	≥ 50	30	≥ 50	30
Transmission accuracy ¹⁾	<2	<1.5	<1.5	<1.5	<1.5	<1
Hysteresis loss	<3	<1	<3	<1	<3	<1
Lost Motion	< 1					
Repeatability	< ± 0.1					

¹⁾ Higher accuracy on request

3.3.5 Torsional Stiffness

Table 16.4

Size	14	17	20	25	32	40	45	50	58	65	80	90
T ₁ [Nm]	2	3.9	7	14	29	54	76	108	168	235	430	618
T ₂ [Nm]	6.9	12	25	48	108	196	275	382	598	843	1570	2260
i = 30	K ₃ [x10 ³ Nm/rad]	3.4	6.7	11	21	49	-	-	-	-	-	-
	K ₂ [x10 ³ Nm/rad]	2.4	4.4	7.1	13	30	-	-	-	-	-	-
	K ₁ [x10 ³ Nm/rad]	1.9	3.4	5.7	10	24	-	-	-	-	-	-
i = 50	K ₃ [x10 ³ Nm/rad]	5.7	13	23	44	98	180	260	340	540	780	1450
	K ₂ [x10 ³ Nm/rad]	4.7	11	18	34	78	140	200	280	440	610	1150
	K ₁ [x10 ³ Nm/rad]	3.4	8.1	13	25	54	100	150	200	310	440	810
i > 50	K ₃ [x10 ³ Nm/rad]	7.1	16	29	57	12	230	330	440	710	980	1850
	K ₂ [x10 ³ Nm/rad]	6.1	14	25	50	11	200	290	400	610	880	1620
	K ₁ [x10 ³ Nm/rad]	4.7	10	16	31	67	130	180	250	400	540	1000

3.3.6 Bearings

Abtriebslagerung

HFUC-2UH units incorporate a high stiffness cross roller bearing to support output loads. This specially developed bearing can withstand high axial and radial forces as well as high tilting moments. The reduction gear is thus protected from external loads, so guaranteeing a long life and constant performance.

The integration of an output bearing also serves to reduce subsequent design and production costs, by removing the need for additional output bearings in many applications. Furthermore, installation and assembly of the reduction gear is greatly simplified. However, in some applications the machine element to be driven requires additional bearing support. In this case, please take care to avoid overdetermination of the bearing arrangement. The cross roller bearing of the Unit should be used as the fixed bearing, whilst the additional support bearing should be floating, if possible. Table 17.1 lists ratings and important dimensions for the output bearings.


Table 17.1

Size		14	17	20	25	32	40	45	50	58	65	80	90
Bearing type ¹⁾		C	C	C	C	C	C	C	C	C	C	C	C
Pitch circle \varnothing	d_p [m]	0.035	0.043	0.050	0.062	0.080	0.096	0.111	0.119	0.141	0.160	0.185	0.214
Offset ²⁾	R [m]	9.5	9.5	9.5	11.5	13.0	14.5	15.5	18.0	20.5	22.5	26.0	28.5
Dynamic load rating	C [N]	4740	5290	5790	9600	15000	21300	23000	34800	51800	55600	76400	82300
Static load rating	C_0 [N]	6070	7550	9000	15100	25000	36500	42600	60200	90400	103000	143000	168000
Permissible dynamic tilting moment ³⁾	M [Nm]	41	64	91	156	313	450	686	759	1180	1860	2740	4210
Permissible static tilting moment ⁴⁾	M_0 [Nm]	53	80	113	234	500	876	1182	1791	3187	4120	6614	8988
Tilting moment stiffness ⁵⁾	K_B [Nm/arcmin]	13	22.5	37	70	157	265	410	497	823	1175	1900	2943
Permissible axial load ⁵⁾	F_a [N]	3374	3207	3511	5827	7926	11242	12174	18393	27409	29371	37611	40895
Permissible radial load ⁵⁾	F_r [N]	2256	2148	2354	3904	6101	8652	9368	14155	21091	22602	25200	27400

Normally, the gear life is determined by the life of the Wave Generator bearing. Depending on the specific load conditions the output bearing can also be determinant for the unit life.

- 1) F = Four-point bearing, C = Cross roller bearing
- 2) See illustration 17.2
- 3) These values are valid for moving gears. They are not based on the equation for lifetime calculation of the output bearing but on the maximum allowable deflection of the Harmonic Drive[®] component set. The values indicated in the table must not be exceeded even if the lifetime equation of the bearing permits higher values.
- 4) These values are valid for gears at a standstill and for a static load safety factor $f_s = 1.8$ for # 14-20 and 1,5 for # 25-58. For other values of f_s , please refer to section 4.7.
- 5) These data are valid for $n = 15$ rpm and $L_{10} = 15000$ h
- 3) 4) 5) These data are only valid if the following conditions are fulfilled:
For: $M, M_0 : F_a = 0, F_r = 0 \mid F_a : M = 0; F_r : M = 0, F_a = 0$
- 6) Average value

Illustration 17.2




Abtriebslager- und Gehäusetoleranzen

Table 18.1

[mm]

Size	14	17	20	25	32	40	45	50	58	65	80	90
a	0.010	0.010	0.010	0.015	0.015	0.015	0.018	0.018	0.018	0.018	0.022	0.022
b	0.010	0.012	0.012	0.013	0.013	0.015	0.015	0.015	0.017	0.017	0.020	0.020
c	0.024	0.026	0.038	0.045	0.056	0.060	0.068	0.069	0.076	0.085	0.090	0.090
d	0.010	0.010	0.010	0.010	0.010	0.015	0.015	0.015	0.015	0.015	0.020	0.020
e	0.038	0.038	0.047	0.049	0.054	0.060	0.065	0.067	0.070	0.075	0.080	0.090

Illustration 18.2



3.3.7 Materials Used

Housing: Cast iron and bearing steel.
 Adapter flange, if supplied by Harmonic Drive AG: high tensile aluminium or steel.

Surfaces:
 Screws: Black phosphatized.
 Housing: Bright.
 Output bearing: Bright bearing steel.

4. Driving Arrangements

A variety of different driving arrangements are possible with Harmonic Drive® gears.


Equation 19.1

Ratio i =	$\frac{\text{Input speed}}{\text{Output speed}}$
-------------	--

Overview Harmonic Drive® Products


The three main components of the Harmonic Drive® units, Circular Spline (CS), Flexspline (FS) and Wave Generator (WG) can be seen in the illustration 19.2.

Illustration 19.2



The values for ratios of Harmonic Drive® gears refer to the standard input and output arrangement (example 1 in the table below). Other arrangements are possible, and also shown in the table.

Ratio




Reduction gearing

CS Fixed
WG Input
FS Output

Equation 20.1

$$\text{Ratio} = - \frac{i}{1}$$

Input and output rotate in opposite directions.




Reduction gearing

FS Fixed
WG Input
CS Output

Equation 20.2

$$\text{Ratio} = \frac{i+1}{1}$$

Input and output rotate in same direction.




Reduction gearing

WG Fixed
FS Input
CS Output

Equation 20.3

$$\text{Ratio} = \frac{i+1}{1}$$

Input and output rotate in same direction.




Speed increaser gearing

WG Fixed
CS Input
FS Output

Equation 20.4

$$\text{Ratio} = \frac{i}{i+1}$$

Input and output rotate in same direction.




Speed increaser gearing

CS Fixed
FS Input
WG Output

Equation 20.5

$$\text{Ratio} = - \frac{1}{i}$$

Input and output rotate in opposite directions.




Speed increaser gearing

FS Fixed
CS Input
WG Output

Equation 20.6

$$\text{Ratio} = \frac{1}{i+1}$$

Input and output rotate in same direction.




Differential gear

WG Control input
CS Main drive input
FS Main drive output

Numerous differential functions can be obtained by combinations of the speed and rotational direction of the three basic elements. Please refer to our brochure "Differential Applications" available to download from our website.

4.1 Selecting Harmonic Drive® Gears

When choosing a gear, both torque as well as stiffness requirements should be taken into account. In robot applications, for example, the necessary torque is the more crucial factor for the gear size, while the torsional stiffness is often decisive in machine tool applications. We therefore recommend that you always take both criteria into account according to the following procedures.




4.1.1 Torque Based Dimensioning

Output Data

Torques	$T_1...T_n$	[Nm]
during the load phases	$t_1...t_n$	[s]
during the pause time	t_p	[s]
and output speeds	$n_1...n_n$	[rpm]
Emergency stop/momentary peak torque	T_k	[Nm]
at output speed	n_k	[rpm]
and duration	t_k	[s]

Illustration 22.1



Equation 22.2

Load limit 1,
Calculation of the average output torque T_{av}

$$T_{av} = \sqrt[3]{\frac{|n_1 \cdot T_1^3| \cdot t_1 + |n_2 \cdot T_2^3| \cdot t_2 + \dots + |n_n \cdot T_n^3| \cdot t_n}{|n_1| \cdot t_1 + |n_2| \cdot t_2 + \dots + |n_n| \cdot t_n}}$$

Equation 22.3

Values for T_A see rating tables
 $T_{av} \leq T_A$

No → Selection of a bigger size

Equation 22.4

Calculation of the average output speed

$$n_{out\ av} = \frac{|n_1| \cdot t_1 + |n_2| \cdot t_2 + \dots + |n_n| \cdot t_n}{t_1 + t_2 + \dots + t_n + t_p}$$

Equation 22.5

Average input speed
 $n_{in\ av} = i \cdot n_{out\ av}$

Equation 22.6

Permissible maximum input speed
 $n_{in\ max} = n_{out\ max} \cdot i \leq$ Maximum input speed (see rating table)

Equation 22.7

Permissible average input speed
 $n_{in\ av} \leq$ Limit for average input speed (s. rating table)

Equation 22.8

Load limit 2, T_R
 $T_{max} \leq T_R$

Equation 22.9

Load limit 3, T_M
 $T_k \leq T_M$

Equation 22.10

Allowable number of momentary peak torques

$$N_{k\ max} = \frac{10^4}{2 \cdot \frac{n_k}{60} \cdot t_k} < 10^4$$

Equation 22.11


Operating life

$$L_{50} = L_n \cdot \frac{\text{Rated input speed}}{n_{in\ av}} \cdot \left(\frac{\text{Rated torque } T_N}{T_{av}} \right)^3$$

Values for L_n see table 24.1

Output Data

$T_1 = 400 \text{ Nm}$	$t_1 = 0.3 \text{ s}$	$n_1 = 7 \text{ rpm}$
$T_2 = 320 \text{ Nm}$	$t_2 = 3.0 \text{ s}$	$n_2 = 14 \text{ rpm}$
$T_3 = 200 \text{ Nm}$	$t_3 = 0.4 \text{ s}$	$n_3 = 7 \text{ rpm}$
$T_k = 500 \text{ Nm}$	$t_k = 0.15 \text{ s}$	$n_k = 14 \text{ rpm}$
	$t_p = 0.2 \text{ s}$	$n_p = 0 \text{ rpm}$
Ratio $i = 120$		
Life $L_{50} = 30000 \text{ h}$ (required)		



4.1.2 Life of the Wave Generator Bearing

Given that the Harmonic Drive® Gear is rated to provide infinite fatigue life for the Flexspline, the life expectancy is based on the average life of the Wave Generator bearing. The rated torque at the rated speed given in the rating table is based on the mean L_{50} bearing life. The life expectancy of a component set or an unit operating at an input speed n (rpm) and output torque T (Nm) may be estimated from equation 24.2.

Table 24.1

[h]

Harmonic Drive® series	L_n
CobaltLine, CSG, SHG	50000
HFUC, HFUS, CSD, CPU, CSF, SHD	35000
PMG gearbox	15000

Equation 24.2

$$L_{50} = L_n \frac{n_N}{n_{in\ av}} \left(\frac{T_N}{T_{av}} \right)^3$$

Equation 24.3

$$L_{10} \approx \frac{1}{5} \cdot L_{50}$$

- n_N = Rated input speed [rpm]
- $n_{in\ av}$ = Average input speed [rpm] (equation 22.5)
- T_N = Rated output torque at rated speed [Nm]
- T_{av} = Average output torque [Nm] (equation 22.2)
- L_n = See table 24.1

4.1.3 Stiffness Based Dimensioning

In addition to the “Torque Based Dimensioning” stated on page 22, we recommend that you carry out a selection based on stiffness. For this, the values provided in table 25.1 for the individual resonance frequencies recommended for each application should be taken into account.

Table 25.1

[Hz]

Application	f_n
Slowly rotating turntables, base axes of slow moving welding robots (not laser welding), slowly rotating welding and swinging tables, gantry robot axes	≥ 4
Base axes of revolute robots, hand axes of revolute robots with low requirements regarding dynamic performance, tool revolvers, tool magazines, swivelling and positioning axes in medical and measuring devices	≥ 8
Standard applications in general mechanical engineering, tilting axes, palette changers, highly dynamic tool changers, revolvers and magazines, hand axes of robots, scara robots, gantry robots, polishing robots, dynamic welding manipulators, base axes of welding robots (laser welding), swivelling and positioning axes of medical equipment	≥ 15
B/C axes in 5 axis grinding machines, hand axes of welding robots (laser welding), milling heads for plastics machining	≥ 20
C axes in turning machines, milling heads for light metal machining, milling heads for woodworking (chipboards etc.)	≥ 25
Milling heads for woodworking (hardwood etc.)	≥ 30
C axes in turning machines*	≥ 35
Milling heads for metal machining*, B axes in turning milling centers for metal machining	≥ 40
Milling heads for metal machining*, B axes in turning milling centers for metal machining with high requirements regarding surface quality*	≥ 50
Milling heads for metal machining with very high requirements regarding surface quality*	≥ 60

* Depending on the application, a secondary gear stage may be useful. Please contact Harmonic Drive AG for more information..

Selection Example: Stiffness Based Dimensioning

Resonance Frequency (Gear Output)

The formula

Equation 26.1

$$f_n = \frac{1}{2\pi} \sqrt{\frac{K_1}{J}} \text{ [Hz]}$$

f_n = Resonance frequency [Hz]

K_1 = Gear torsional stiffness K_1 [Nm/rad]

J = Load moment of inertia [kgm²]

allows the calculation of the resonance frequency at the gear output from the given torsional stiffness, K_1 , of the Harmonic Drive[®] gear and the load's moment of inertia. The calculated frequency should correspond with the value provided in table 25.1. The higher the load's moment of inertia, the more influence the application has on the gear selection. If the moment of inertia = 0, the selected application has no numerical influence on the selection result.

Resonance Speed (Gear Input)

The resonance speed n_n on the input side (motor side) can be calculated using the formula

$$n_n = f_n \cdot 30 \text{ [rpm]}$$

During operation, we recommend that you pass the resonance speed rapidly. This can be achieved by selecting a suitable gear ratio. Another possibility is to select suitable gear stiffness such that the resonance speed lies beyond the required speed range.

Selection Example

HFUC-40-120-2A-GR preselected from "Selection Procedure" on page 23.

Intended application: milling head for woodworking

Moment of inertia at the gear output: 7 kgm². Recommended resonance frequency from table 25.1: ≥ 30 Hz.

Resonance frequency using the preselected gear

HFUC-40-120-2A-GR:

$$f_n = \frac{1}{2\pi} \sqrt{\frac{1.3 \cdot 10^5}{7}} = 22 \text{ [Hz]}$$

According to stiffness based dimensioning, this gear size is too small for the application.

The larger gear HFUC-50-120-2A-GR results in a resonance frequency of:

$$f_n = \frac{1}{2\pi} \sqrt{\frac{2.5 \cdot 10^5}{7}} = 30 \text{ [Hz]}$$

Based on stiffness based dimensioning, the gear HFUC-50-120-2A-GR is recommended.

The resonance speed at the input (motor) amounts to:

$$n_n = 30 \cdot 30 = 900 \text{ [rpm]}$$

Either, this speed should be passed without stopping when accelerating / braking, or it should lie beyond the utilised speed range.

4.2 Calculation of the Torsion Angle

Calculation of the Torsion Angle φ at Torque T:

Equation 27.1

$$T \leq T_1$$

$$\varphi = \frac{T}{K_1}$$

Equation 27.2

$$T_1 < T \leq T_2$$

$$\varphi = \frac{T_1}{K_1} + \frac{T - T_1}{K_2}$$

Equation 27.3

$$T > T_2$$

$$\varphi = \frac{T_1}{K_1} + \frac{T_2 - T_1}{K_2} + \frac{T - T_2}{K_3}$$

φ = Angle [rad]
 T = Torque [Nm]
 K = Stiffness [Nm/rad]

Example: HFUC-32-100-2UH

$$T = 60 \text{ Nm} \quad K_1 = 6.7 \cdot 10^4 \text{ Nm/rad}$$

$$T_1 = 29 \text{ Nm} \quad K_2 = 1.1 \cdot 10^5 \text{ Nm/rad}$$

$$T_2 = 108 \text{ Nm} \quad K_3 = 1.2 \cdot 10^5 \text{ Nm/rad}$$

$$\varphi = \frac{29 \text{ Nm}}{6.7 \cdot 10^4 \text{ Nm/rad}} + \frac{60 \text{ Nm} - 29 \text{ Nm}}{1.1 \cdot 10^5 \text{ Nm/rad}}$$

$$\varphi = 7.15 \cdot 10^{-4} \text{ rad}$$

$$\varphi = 2.5 \text{ arc min}$$

Equation 27.4

$$\varphi \text{ [arc min]} = \varphi \text{ [rad]} \cdot \frac{180 \cdot 60}{\pi}$$

4.3 Accuracy of the Oldham Coupling

Information concerning the Oldham coupling can be found in section 5.7.2.

In the region of tooth engagement Harmonic Drive® gears have no backlash. If an Oldham coupling is used for the compensation of eccentricity errors of the motor shaft, a small backlash in the range of a few seconds of arc can occur at the output shaft, as listed in table 27.5.

Table 27.5

[arcsec]


Sizes		14	17	20	25	32	40	45	50	58	65	80	90
Ratio	30	60	33	28	28	23	-	-	-	-	-	-	-
	50	36	20	17	17	14	14	12	12	10	10	10	8
	80	23	13	11	11	9	9	8	8	6	6	6	5
	100	18	10	9	9	7	7	6	6	5	5	5	4
	120	-	8	8	8	6	6	5	5	4	4	4	3
	160	-	-	6	6	5	5	4	4	3	3	3	2

4.4 Efficiency Versus Load

Efficiency for Harmonic Drive® gears varies depending on the output torque. The efficiency curves are for gears operating at rated output torque. Efficiency for a gear operating at a load below the rated torque may be estimated using a compensation curve and equation as shown on the next page.


4.4.1 Efficiency Calculations

Table 28.1

Calculation Procedure	Example
	Efficiency of HFUC-20-80-2A-GR with input speed n=1000 rpm output torque T=19.6 Nm at 20° C ambient temperature. Lubrication: Grease
The efficiency may be determined using the efficiency graphs.	From matching chart $\eta = 78\%$
Calculate the torque factor V. $V = \frac{T_{av}}{T_N} \quad \text{[Equation 28.2]}$ With: T _{av} = Average torque T _N = Rated torque at rated speed	T _{av} = 19.6 Nm T _N = 34.0 Nm $V = \frac{19.6 \text{ Nm}}{34.0 \text{ Nm}} = 0.57$
K depending on gear type and V, see illustration 28.4	
Efficiency $\eta_L = \eta \cdot K$ [Equation 28.3]	$\eta_L = 78 \cdot 0.93 = 73\%$

Calculating Factor K

Illustration 28.4



4.4.2 Efficiency Tables

Efficiency for grease lubrication at rated torque Harmonic Drive® grease

Size 14

Illustration 29.1









Illustration 30.1



4.5 Free Load Torques

No Load Running Torque

The no load running torque is the torque required to maintain rotation of the input element (high speed side) at a defined input speed with no load applied to the output.

No Load Starting Torque

The no load starting torque is the quasistatic torque required to commence rotation of the input element (high speed side) with no load applied to the output element (low speed side).

No Load Back Driving Torque

The no load back driving torque is the torque required to commence rotation of the output element (low speed side) with no load applied to the input element (high speed side). The approximate range for no load back driving torque, based on tests of actual production gears, is shown in the matching table. In no case should the values given be regarded as a margin in a system that must hold an external load. Where back driving is not permissible a brake must be fitted.

The following curves are valid for: Harmonic Drive® grease, standard lubricant quantity


Gear ratio $i = 100$

For other ratios please apply the compensation values below.

For oil lubrication please contact Harmonic Drive AG.

4.5.1 No Load Running Torque

Illustration 31.1



Compensation Values for No Load Running Torque

When using gears with ratios other than $i \neq 100$, please apply the compensation values from the table to the values taken from the curves

Table 32.1

[Ncm]

Ratio	Size											
	14	17	20	25	32	40	45	50	58	65	80	90
30	2.5	3.8	5.4	8.8	16.0	-	-	-	-	-	-	-
50	1.1	1.6	2.3	3.8	7.1	12	16	21	30	41	67	91
80	0.2	0.3	0.5	0.7	1.3	2.1	2.9	3.7	5.3	8.1	12	17
120	-	-0.2	-0.3	-0.5	-0.9	-1.5	-2.1	-2.6	-3.8	-5.8	-8	-12
160	-	-	-0.8	-1.2	-2.2	-3.5	-4.9	-6.2	-8.9	-13.7	-21	-30

4.5.2 No Load Starting Torque

Table 32.2

[Ncm]

Ratio	Size											
	14	17	20	25	32	40	45	50	58	65	80	90
30	6.4	9.3	15	25	54	-	-	-	-	-	-	-
50	4.1	6.1	7.8	15	31	55	77	110	160	220	360	500
80	2.8	4.0	4.9	9.2	19	35	49	66	98	140	230	320
100	2.5	3.4	4.3	8.0	18	31	43	58	88	120	200	280
120	-	3.1	3.8	7.3	15	28	39	52	80	110	190	250
160	-	-	3.3	6.3	14	24	33	45	68	93	155	220

4.5.3 No Load Back Driving Torque

Table 32.3

[Nm]

Ratio	Size											
	14	17	20	25	32	40	45	50	58	65	80	90
30	2.4	3.8	6.2	11	23	-	-	-	-	-	-	-
50	1.6	3.0	4.7	9.0	18	33	47	62	95	130	220	300
80	1.6	3.0	4.8	9.1	19	33	48	63	96	140	220	300
100	1.8	3.3	5.1	9.8	20	36	51	68	110	150	230	330
120	-	3.5	5.5	11	22	39	55	73	110	160	250	350
160	-	-	6.4	13	26	46	64	85	130	180	300	410

4.6 Life for Continuous Operation

The operating life of the output bearing can be calculated using equation 33.1.

Equation 33.1

$$L_{10} = \frac{10^6}{60 \cdot n_{av}} \cdot \left(\frac{C}{f_w \cdot P_c} \right)^B$$

with:

- L_{10} [h] = Operating life
- n_{av} [rpm] = Average output speed (equation 33.2)
- C [N] = Dynamic load rating (see table 17.1)
- P_c [N] = Dynamic equivalent load (equation 34.1)
- f_w = Operating factor (table 33.3)
- B = Bearing type (table 33.4)

Average Output Speed

Equation 33.2

$$n_{av} = \frac{|n_1| t_1 + |n_2| t_2 + \dots + |n_n| t_n}{t_1 + t_2 + \dots + t_n + t_p}$$

Table 33.3

Load conditions	f_w
No impact loads or vibrations	1 ... 1.2
Normal rotating, normal loads	1.2 ... 1.5
Impact loads and/or vibrations	1.5 ... 3

Table 33.4

Bearing type	B
Cross roller bearings	10/3
Four point contact bearings	3

Dynamic Equivalent Load

Equation 34.1

$$P_c = x \cdot \left(F_{rav} + \frac{2M}{d_p} \right) + y \cdot F_{aav}$$

with:

F_{rav} [N] = Radial force (equation 34.2)

x = Radial load factor (table 34.4)

F_{aav} [N] = Axial force (equation 34.3)

y = Axial load factor (table 34.4)

d_p [m] = Pitch circle (table 17.1)

M = Tilting moment (illustration 17.2)

Equation 34.2

$$F_{rav} = \left(\frac{|n_1| \cdot t_1 \cdot (|F_{r1}|)^B + |n_2| \cdot t_2 \cdot (|F_{r2}|)^B + \dots + |n_n| \cdot t_n \cdot (|F_{rn}|)^B}{|n_1| \cdot t_1 + |n_2| \cdot t_2 + \dots + |n_n| \cdot t_n} \right)^{1/B}$$


Equation 34.3

$$F_{aav} = \left(\frac{|n_1| \cdot t_1 \cdot (|F_{a1}|)^B + |n_2| \cdot t_2 \cdot (|F_{a2}|)^B + \dots + |n_n| \cdot t_n \cdot (|F_{an}|)^B}{|n_1| \cdot t_1 + |n_2| \cdot t_2 + \dots + |n_n| \cdot t_n} \right)^{1/B}$$

Table 34.4

Load factors	x	y
$\frac{F_{aav}}{F_{rav} + 2 \cdot M / d_p} \leq 1.5$	1	0.45
$\frac{F_{aav}}{F_{rav} + 2 \cdot M / d_p} > 1.5$	0.67	0.67

Illustration 34.5



Please note:

F_{rx} = represents the maximum radial force.

F_{ax} = represents the maximum axial force.

t_p = represents the pause time between cycles.

4.6.1 Output Bearing at Oscillating Motion

Life for Oscillating Motion

The operating life at oscillating motion can be calculated using equation 35.1

Equation 35.1

$$L_{oc} = \frac{10^6}{60 \cdot n_1} \cdot \frac{180}{\varphi} \cdot \left(\frac{C}{f_w \cdot P_c} \right)^B$$

with:


- L_{oc} [h] = Operating life for oscillating motion
- n_1 [cpm] = Number of oscillations/minute*
- C [N] = Dynamic load rating (table 17.1)
- P_c [N] = Dynamic equivalent load (equation 34.1)
- φ [deg] = Oscillating angle
- f_w = Operating factor (table 33.3)

* one oscillation means 2φ

Oscillating angle

At oscillating angles $< 5^\circ$ fretting corrosion may occur due to insufficient lubrication. In this case please contact our sales engineer for counter measures.

Illustration 35.2



4.7 Permissible Static Tilting Moment

In case of static load, the bearing load capacity can be determined as follows:

Equation 36.1

$$f_s = \frac{C_0}{P_0} \text{ mit } P_0 = x_0 \left(F_r + \frac{2M}{d_p} \right) + \gamma_0 \cdot F_a$$

and so

Equation 36.2

$$M_0 = \frac{d_p \cdot C_0}{2 \cdot f_s}$$

f_s = Static load safety factor

($f_s = 1.5 \dots 3$) (table 36.3)

C_0 = Static load rating (table 17.1)

F_r = $F_a = 0$

$x_0 = 1$

$\gamma_0 = 0.44$

P_0 = Static equivalent load (equation 36.1)

d_p = Pitch circle diameter of the output bearing (table 17.1)

M = Moment acting (illustration 17.2)

M_0 = Allowable static overturning moment

Table 36.3

Rotation conditions of bearing	Lower limit value for f_s
Normal	≥ 1.5
Vibrations / Impacts	≥ 2
High transmission accuracy	≥ 3

4.8 Angle of Inclination

The angle of inclination of the output flange, as a function of the tilting moment acting on the output bearing, can be calculated by means of equation 36.4:

Equation 36.4

$$\gamma = \frac{M}{K_B}$$

with:

γ [arcmin] = Angle of inclination of the output flange

M [Nm] = Tilting moment acting on the output bearing

K_B [Nm/arcmin] = Moment stiffness of the output bearing (table 17.1)

4.9 Lubrication

Ratings and Lubricants

Harmonic Drive® products achieve the specified ratings and characteristics in the standard ambient temperature range (0° C to 40° C) when they are used with the lubricants named in the catalogue. Harmonic Drive AG can guarantee for the data specified in the catalogue only if a Harmonic Drive® grease or a mineral oil qualified for the specific product used. Lubricants and lubricant quantities other than recommended by Harmonic Drive AG should be qualified by means of prototype tests, as necessary.

The warranty becomes void when lubricants that have not been recommended in the Harmonic Drive® catalogue or that have not been approved in writing for the specific application are used.

4.9.1 Grease Lubrication

Application of Harmonic Drive® Lubricating Grease

Depending on product, size and if necessary ratio, the matching Harmonic Drive® grease should be selected. We recommend the application of the Harmonic Drive® lubricating greases according to the data in the tables 37.1 and 37.2.

Caution!

The Harmonic Drive® high performance 4BNo.2 grease becomes relatively thin during operation. Therefore the design must be oil-tight. Because of the special characteristics of this grease, a small base oil leakage at the oil seals can not completely be ruled out.

Table 37.1

Grease	Ratio ≥ 50														
	Size														
	8	11	14	17	20	25	32	40	45	50	58	65	80	90	100
Flexolub A1	-	Standard for CPU and CobaltLine													
SK-1A	-			Standard											
SK-2	Standard			-											
4BNo.2	-	For heavy duty operation*													

Table 37.2

Grease	Ratio = 30						
	Size						
	8	11	14	17	20	25	32
Flexolub A1	-		Standard for CPU				
SK-1A	-			Standard			
SK-2	Standard			-			
4BNo.2	-			For heavy duty operation*			

Notes:

* = recommended for heavy duty operation or at operating temperatures ranging from -10° C to +110° C
 - = not approved

Table 38.1 gives some important information regarding Harmonic Drive® lubricating greases.

Table 38.1

Type	Harmonic Drive® lubricating greases			
	Standard		Special	
	SK-1A	SK-2	Flexolub A1	4BNo.2
Operating temperature range	0° C ... +80° C	0° C ... +80° C	-40° C ... +120° C	-10° C ... +110° C
Base oil	Mineral oil	Mineral oil	PAO / Ester oil	Synthetic oil
Thickener	Lithium soap	Lithium soap	Lithium soap	Urea
Consistency class (NLGI)	2	2	1	1-2
Base oil viscosity (40° C; 100° C)	37; 5,9 mm ² /St	37; 5,9 mm ² /St	25; 5,2 mm ² /St	50; 12 mm ² /St
Drop point	197° C	198° C	180° C	247° C
Colour	yellow	green	magenta	pale yellow
Max. storage time in hermetically sealed container	5 years			
Ease of sealing (safety against grease- or base oil leakage at the oil seals)	+	+	+	+/-

Notes:

+ = Good

+/- = May be critical depending on design / mounting position / application, please contact Harmonic Drive AG

Safety data sheets and technical data sheets for the Harmonic Drive® lubricants are available from Harmonic Drive AG.

Special Operating Demands

Table 39.1 shows examples of lubricants for special operating demands. In individual cases other lubricants may be recommendable, and special limit values may have to be considered for product calculations at extended operating temperatures. Please ask Harmonic Drive AG for more information.

Table 39.1

Lubricants for special operating demands			
Application	Type	Manufacturer, Designation	Operating temperature range ¹⁾
Broadband temperature range	Grease	Harmonic Drive®, Flexolub-A1	-40° C ... +120° C ³⁾
Low temperature	Grease Oil	Harmonic Drive®, Flexolub-M0	-50° C ... +120° C ²⁾⁵⁾
High temperature	Grease Oil	Mobil, Mobil Grease 28 Mobil, Mobil SHC 626	-55° C ... +160° C ²⁾ -15° C ... +140° C ²⁾
Food-/pharmaceutical industry	Grease	Bechem, Berulub FG-H 2 SL	-40° C ... +120° C ²⁾⁴⁾

Notes:

- ¹⁾ Operating temperature = Lubricant temperature
- ²⁾ User specific prototype tests recommended
- ³⁾ Applicability confirmed for all Harmonic Drive® catalogue products with cup type Flexspline for size 14 and up. 1 kg bundles available at HDAG
- ⁴⁾ NSF-H1 certification. Applicability confirmed for HFUC-XX, CPU-XX, HFUS-XX, CPL-XX, CHA-XX with i=100 at full usage of the catalogue performance data. Please consult Harmonic Drive AG for i>100 applications. For food/ pharmaceutical compatibility, grease change is necessary for output- and support bearings, if used. 400 g bundles available at Harmonic Drive AG.
- ⁵⁾ Recommended for applications requiring best possible efficiency at low temperatures. Not suitable for high output torque.

4.9.2 Oil Lubrication

Harmonic Drive® units with oil lubrication are customer specific solutions. Oil quantity and change interval are specified individually.

Table 39.2

Shared lubricating oils				
Manufacturer	Klüber	Mobil	Castrol	Shell
Designation	Syntheso D 68 EP	Mobilgear 600 XP 68	Optigear BM 68	Omala S2 G 68

Please note the information in section 5.5.5.

4.10 Axial Forces at the Wave Generator

When a Harmonic Drive® Gear is used as a speed reducer (torque input via Wave Generator), the deflection of the Flexspline leads to an axial force acting on the Wave Generator. This axial force acts in the direction of the Flexspline diaphragm. When the Harmonic Drive® Component Set is used as a speed accelerating gear (reverse operation, e. g. when braking), the axial force acts in the opposite direction. In any case the axial force must be absorbed by the input shaft (motor shaft). The Wave Generator thus needs to be fixed on the input shaft in the axial direction. In closed Harmonic Drive® units and gearboxes the axial force is absorbed internally.

Illustration 40.1




Table 40.2

Ratio		
30	$F_{AX} = 2 \cdot \frac{T}{D} \cdot \mu \cdot \tan 32^\circ$	[Equation 40.3]
50	$F_{AX} = 2 \cdot \frac{T}{D} \cdot \mu \cdot \tan 30^\circ + 2\mu PF$	[Equation 40.4]
80...160	$F_{AX} = 2 \cdot \frac{T}{D} \cdot \mu \cdot \tan 20^\circ + 2\mu PF$	[Equation 40.5]

with:

- F_{AX} = Axial force [N]
- D = (Size) · 0.00254 [m]
- T = Torque at the output [Nm]
- μ = 0.07 Coefficient of friction
- $2\mu PF$ = Additional force (only CSD) [N]

Example

Size 32 (CSD-32-50)
 Output torque = 300 Nm
 Coefficient of friction $\mu = 0.07$

$$F_{AX} = 2 \cdot \frac{200 \text{ Nm}}{(32 \cdot 0.00254) \text{ m}} \cdot 0.07 \cdot \tan 30^\circ + 16$$

$$F_{AX} = 215 \text{ N}$$

Table 40.6

Sizes	14	17	20	25	32	40	50
$2\mu PF$ [N] for CSD and SHD	2.1	4.1	5.6	9.8	16	24	39

5. Installation and Operation

5.1 Transport and Storage

Gears should be transported in the original packaging. If the gear is not put into service immediately on receipt, it should be stored in a dry area in the original packaging. The permissible storage temperature range is -20° C to +60° C.

5.2 Gear Condition at Delivery

The gears are generally delivered according to the dimensions indicated in the confirmation drawing.

Gears with Grease Lubrication

Units are supplied with grease lubricant as standard.

Gears with Oil Lubrication

Harmonic Drive® Units with oil lubrication are generally customer-specific solutions. Please follow the notes given on the confirmation drawing. The oil temperature during operation must not exceed 90° C. Oil must be filled into the unit by the customer as the standard delivery does not include any oil lubricant.

Oil Quantity

The values specified in the confirmation drawing include the valid oil quantities to fill in. The oil quantity defined on the confirmation drawing must be obeyed in any case. Too much oil results in excessive heat production and early wear due to the thermal destruction of the oil. If the oil level is too low, this may lead to early wear as a result of lubricant deficiency.

5.3 Assembly Information

ADVICE

Screws which have been tightened by the gear manufacturer must not be loosened.

5.4 Recommended Tolerances for Assembly

In order for the new features of Harmonic Drive® Units to be exploited fully, it is essential that the tolerances according to table 42.2 are observed for the input assembly.




Table 42.2

[mm]

Size	14	17	20	25	32	40	45	50	58	65	80	90
a	0.011	0.015	0.017	0.024	0.026	0.026	0.027	0.028	0.031	0.034	0.043	0.050
b	0.017 (0.008)	0.020 (0.010)	0.020 (0.010)	0.024 (0.012)	0.024 (0.012)	0.032 (0.012)	0.032 (0.013)	0.032 (0.015)	0.032 (0.015)	0.032 (0.015)	0.036 (0.015)	0.036 (0.015)
c	0.030 (0.016)	0.034 (0.018)	0.044 (0.019)	0.047 (0.022)	0.050 (0.022)	0.063 (0.024)	0.065 (0.027)	0.066 (0.030)	0.068 (0.033)	0.070 (0.035)	0.090 (0.043)	0.091 (0.046)

The values in brackets are the recommended tolerances for component sets featuring a Wave Generator without Oldham coupling. The Oldham coupling serves to compensate for eccentricity of the input shaft and is available in the standard version. For the direct mounting of a Wave Generator without Oldham coupling (optional) on a motor shaft, the shaft tolerances should fulfill the DIN 42955 R standard.


5.5 Lubrication

Harmonic Drive® Units are delivered ready for immediate installation. They are supplied with lifetime lubricant which is a high performance grease that meets the specific requirements of the Harmonic Drive® gears. It guarantees constant accuracy of the gears for their whole life. A re-lubrication of the Units is not necessary.

5.5.1 Grease Lubrication

Units are supplied with standard grease lubricant. Illustration 42.3 shows the sections where lubrication is required and which are filled with grease lubrication at the time of delivery. If no special arrangements are made the specially developed high performance grease SK-1A (for sizes 20 to 90) and SK-2 (for size 14 and 17) are used. If any other grease is used this will be indicated on the customer drawing. High performance 4BNo. 2 grease with improved.

Illustration 42.3



5.5.2 Amount of Grease

Illustration 43.1





Table 43.2

[mm]

Size	14	17	20	25	32	40	45	50	58	65	80	90	100
D	28	33	40	50	66	79	88	98	115	132	160	180	200
S	3	4	4.5	5.5	7	9.5	11	12	13.5	13.5	18	20.5	22

Illustration 43.3



5.5.3 Additional Grease Package

When the unit is mounted to the motor with the adaptor flange design recommended by Harmonic Drive AG, the unit can be used in all operating positions. To achieve the maximum gear life, we recommend that an additional grease package is provided in the grease reservoir between Wave Generator and motor d-shield during assembly, see illustration 44.2

Table 44.1

Size		14	17	20	25	32	40	45	50	58	65	80	90	100
Standard grease quantity	ca. [g]	5.5	10	16	40	60	130	180	260	360	440	850	990	1636
	ca. [cm ³]	6	11	18	44	66	143	198	286	396	484	935	1089	1800
Additionally required grease quantity for operation with Wave Generator above	ca. [g]	3	4	9	13	22	44	59	72	117	141	259	333	490
	ca. [cm ³]	3	5	9	14	24	49	65	79	129	155	285	366	540

Illustration 44.2




Illustration 44.3




Table 44.4

[kg]


Ordering code	Available packaging
Special grease SK-1A. SK-2	0.5; 2.5; 16
Special grease 4BNo.2	0.5; 2; 16
Special grease Flexolub-A1	1.0; 25

5.5.4 Grease Change

To change the grease the component set should be completely disassembled and cleaned before regreasing. Fresh grease should be applied generously to the inside of the Flexspline, the Wave Generator bearing, the Oldham coupling and the teeth of the Circular Spline and Flexspline.

In illustration 45.1, the grease change interval depending on the grease temperature is given. The number of allowable revolutions of the input shaft which represents the grease change interval can be estimated as shown in the example. This means, that for a temperature of SK-1A or SK-2 grease of 40°C a change should take place after approx. 8.5×10^8 revolutions of the input shaft. All grease change data refers to rated speed and rated torque.

Illustration 45.1



Gleichung 45.2

$$L_{GT} = L_{GTn} \cdot \left(\frac{T_r}{T_{av}} \right)^3$$

L_{GT} = Number of Wave Generator revolutions until grease change

L_{GTn} = see diagram

T_r = Rated torque

T_{av} = Average torque

5.5.5 Oil Lubrication

Harmonic Drive® Units with oil lubrication are generally customer-specific solutions. Please follow the notes given on the confirmation drawing and refer to table 39.2 for allowed oil types. The oil temperature during operation must not exceed 90°C. Oil must be filled into the unit by the customer as the standard delivery does not include any oil lubricant.

The values specified in the confirmation drawing include the valid oil quantities to fill in. The oil quantity defined on the confirmation drawing must be obeyed in any case. Too much oil results in excessive heat production and early wear due to the thermal destruction of the oil. If the oil level is too low, this may lead to early wear as a result of lubricant deficiency.

The first oil change is necessary after 100 hours of operation. Subsequent oil change intervals depend on the operating conditions, but should take place at intervals of approximately 1000 running hours.

To change the oil, the used oil must be drained completely and fresh oil must be filled in. Permitted oil types see in table 39.2. The mixture of lubricants of different specifications should generally be avoided.

5.6 Assembly

Assembly preparation

The gear assembly must be carried out very carefully and within a clean environment. Please make sure that during the assembly procedure no foreign particles enter the gear.

General information

Clean, degrease and dry all mating surfaces to ensure an adequate coefficient of friction. The values given in table 8 are valid for 12.9 quality screws which must be tightened by means of a torque wrench. Locking devices such as spring washers or toothed washers should not be used.

Auxiliary materials for assembly

For the assembly, we recommend the application of the following auxiliary materials or the use of those with similar characteristics. Please pay attention to the application guidelines given by the manufacturer. Auxiliary materials must not enter the gear.

Surface sealing

- Loctite 5203
- Loxeal 28-10

Recommended for all mating surfaces, if the use of o-ring seals is not intended. Flanges provided with O-ring grooves must be sealed with sealing compound when a proper seal cannot be achieved using the O-ring alone.

Screw fixing

- Loctite 243

This adhesive ensures that the screw is fixed and also provides a good sealing effect. Loctite 243 is recommended for all screw connections.

Assembly paste

- Klüber Q NB 50

Recommended for o-rings which may come out of the groove during the assembly procedure. Before starting with the assembly you should spread some grease (which you can take from the gear) on all other o-rings.

Adhesives

- Loctite 638

Apply Loctite 638 to the connections between motor shaft and Wave Generator. You should make use of it only if this is specified in the confirmation drawing.

5.7 Mounting


5.7.1 Motor Assembly

The Units have been designed for simple motor assembly. This means that the Wave Generator is mounted directly on the motor shaft. When ordering please indicate which motor type is to be used, so that the Wave Generator can be manufactured to match. If required, units can be provided including the motor adaptor flange or with a ready assembled motor. In addition to the correct dimensioning of the motor, particular attention must be paid to the geometric tolerances of the motor output flange and motor shaft. The shaft and flange tolerances of the motor should fulfill the requirements of the DIN 42955 standard. To fully exploit the excellent performance characteristics of the units we recommend the use of motors fulfilling DIN 42955 R tolerances.

Adaptor Flange

The transmission accuracy of the gearbox is dependent on the manufacturing accuracy of the motor adaptor flange. Table 47.2 shows the recommended tolerances for the motor with assembled adaptor flange.

Illustration 47.1



ADVICE

For the manufacturing of the adaptor flange we recommend the dimensions and tolerances given in table 47.2. To achieve the given value for concentricity and run out we recommend that the motor- and gear side flange surfaces are manufactured at a single clamping.

Table 47.2

Size	14	17	20	25	32	40	45	50	58	65	80	90
a	0.030	0.040	0.040	0.040	0.040	0.050	0.050	0.050	0.050	0.050	0.050	0.063
b	0.030	0.040	0.040	0.040	0.040	0.050	0.050	0.050	0.050	0.050	0.050	0.063
c	0.015	0.015	0.018	0.018	0.018	0.018	0.021	0.021	0.021	0.021	0.021	0.021
ϕA	73	79	93	107	138	160	180	190	226	260	294	324
t	3	3	4	4	4	5	5	5	6	6	7	7
ϕT H7	38	48	56	67	90	110	124	135	156	177	218	245

Mounting


As shown in illustration 48.2 and 48.3, there are two basic methods of assembly. Table 48.1 provides recommendations concerning the appropriate assembly procedure.

Table 48.1

[mm]

Size	14	17	20	25	32	40	45	50	58	65	80	90	Assembly according to illustration
Motor-Centering - \varnothing	<35.5	<43.5	<50.0	<62.5	<81.5	<100.0	<113.5	<124.5	<147	<167	<206	<230	48.2
	≥ 35.5	≥ 43.5	≥ 50.0	≥ 62.5	≥ 81.5	≥ 100.0	≥ 113.5	≥ 124.5	≥ 147	≥ 167	≥ 206	≥ 230	48.3


Illustration 48.2



Installation steps as shown in illustration 48.2:

- 1) Mount the flange assembly to the motor.
- 2) Mount the Wave Generator to the motor shaft.
- 3) Installation of the flange including motor onto the unit.

Illustration 48.3




Installation steps according to illustration 48.3:

- 1) Mount the flange to the Unit.
- 2) Mount the wave generator to the motor shaft.
- 3) Mount the motor onto the flange.

5.7.2 Wave Generator Components

Illustration 49.1 shows a standard Wave Generator with Oldham Coupling.

Illustration 49.1




- 1) Ball Separator
- 2) Wave Generator bearing
- 3) Wave Generator plug
- 4) Insert
- 5) Thrust washers
- 6) Snap ring
- 7) Wave Generator hub

Wave Generator Modifications

HFUC-2UH units are provided with an Oldham coupling to compensate for eccentricity of the input shaft see illustration 49.2.

Principle of an Oldham Coupling

Illustration 49.2



Bore Diameter for Solid Wave Generator

If a large-bore Wave Generator or an input coupling completely free of backlash is required, the Oldham coupling may be removed and the input shaft can be attached directly to the Wave Generator plug. This is the so called "Solid Wave Generator" configuration. The Wave Generator bore may be enlarged or splined to accept a hollow shaft or a splined shaft. The maximum allowable bore diameter, with or without keyway or splines, is given in table 50.2. Use of a Solid Wave Generator demands tighter tolerances for the motor shaft

Maximum Bore Diameter without Oldham Coupling

Illustration 50.1




Table 50.2

[mm]

Size	14	17	20	25	32	40	45	50	58	65	80	90
L_w for keys to DIN 6885 T1	12	13	17	22	28	34	39	44	50	56	61	73
L	17	20	23	28	36	42	47	52	60	67	72	84

5.7.3 Mounting the Wave Generator (WG) to the Motor Shaft

The units are delivered with the Wave Generator adapted for the motor shaft. The hub of the Oldham coupling is secured on the motor shaft by means of a key or clamping element. Please observe the recommendations for the correct axial position of the Wave Generator inside the gearbox.

The axial attachment of the hub must withstand the axial forces acting on the Wave Generator. When mounted correctly, the motor shaft should extend at least 2/3 of the entire hub length, thereby ensuring reliable transmission of the motor torque.

Illustration 51.1 Units with Keyway





Illustration 51.2 Units with Clamping Element



For stepping motor operation and for large motor shaft diameters the use of a solid Wave Generator is recommended. Illustration 51.2 shows the standard version with Oldham coupling and keyway. Illustration 51.2 shows a solid Wave Generator without Oldham coupling. The Wave Generator is attached directly to the motor shaft by means of a clamping element.

5.7.4 Check Before Assembly of the Wave Generator (WG)

- Final check of position of the Wave Generator. For some clamping elements an axial movement may occur during tightening. Please take account of this effect when positioning the Wave Generator on the shaft.
- Check whether the WG is lubricated in accordance with illustration 59.3. When the gear is oil lubricated, fill in the prescribed oil quantity.

5.7.5 Assembly Control


Very rarely, an eccentric tooth mesh, called dedoidal, may occur.

The correct assembly can be checked as follow:

- Check the running behaviour by rotating the input shaft (in case of types with input shaft). Alternatively you may rotate the output flange. If you notice torque variations these may be caused by eccentric tooth mesh.
- Check the running behaviour and the motor current while the motor is rotating. Strong fluctuations in the motor current and/or an excessive no-load current may be the result of an eccentric tooth mesh.

In case of a dedoidal assembly you can avoid permanent damage to the gear if the wrong installation is recognized by means of the above mentioned inspection. The problem can be solved by disassembling the gear followed by a new assembly.

Illustration 52.1



5.7.6 Assembly of the Output Flange

Illustration 53.1




Table 53.2

Size	14	17	20	25	32	40	45	50	58	65	80	90
Number of Bolts	6	6	8	8	8	8	8	8	8	8	12	12
Bolt Size	M4	M5	M6	M8	M10	M10	M12	M14	M16	M16	M16	M16
Bolt pitch diameter [mm]	23	27	32	42	55	68	82	84	100	110	135	160
Tightening Torque [Nm]	4.5	9	15.3	37	74	74	128	205	319	319	319	319
Torque transmitting capacity* [Nm]	48	91	206	490	1010	1240	2200	3070	4980	5480	10200	12100

5.7.7 Assembly of the Housing Flange

Table 53.3

Size	14	17	20	25	32	40	45	50	58	65	80	90
Number of Bolts	6	6	6	8	12	8	12	12	12	8	12	12
Bolt Size	M4	M4	M5	M5	M6	M8	M8	M8	M10	M12	M12	M12
Bolt pitch diameter [mm]	65	71	82	96	125	144	164	174	206	236	270	300
Tightening Torque [Nm]	4.5	4.5	9	9	15.3	37	37	37	74	128	128	128
Torque transmitting capacity* [Nm]	137	147	274	431	1200	1680	2860	3040	5670	6310	10025	11245

* Friction coefficient $\mu = 0.15$; 12.9 quality screws

6. Glossary

6.1 Technical Data

AC Voltage constant k_{EM} [$V_{rms} / 1000 \text{ rpm}$]

Effective value of the induced motor voltage measured at the motor terminals at a speed of 1000 rpm and an operating temperature of 20° C.

Ambient operating temperature [°C]

The intended operating temperature for the operation of the drive.

Average input speed (grease lubrication) $n_{av(max)}$ [rpm]

Maximum permissible average gear input speed for grease lubrication.

Average input speed (oil lubrication) $n_{av(max)}$ [rpm]


Maximum permissible average gear input speed for oil lubrication.

Average torque T_A [Nm]

When a variable load is applied to the gear, an average torque should be calculated for the complete operating cycle. This value should not exceed the specified T_A limit.

Backlash (Harmonic Planetary gears) [arcmin]

When subjected to the rated torque, Harmonic Planetary gears display characteristics shown in the hysteresis curve. When a torque is applied to the output shaft of the gear with the input shaft locked, the torque-torsion relationship can be measured at the output. Starting from point O the graph follows successive points A-B-A-B-A A where the value B-B is defined as the backlash or hysteresis.



Brake closing time t_c [ms]

Delay time to close the brake.

Brake current to hold I_{HBr} [A_{DC}]

Current for applying the brake.

Brake current to open I_{OBr} [A_{DC}]

Current required to open the brake.

Brake holding torque T_H [Nm]

Torque the actuator can withstand when the brake is applied, with respect to the output.

Brake opening time t_o [ms]

Delay time for opening the brake.

Brake voltage U_{Br} [VDC]

Terminal voltage of the holding brake.

Collision torque T_M [Nm]

In the event of an emergency stop or collision, the Harmonic Drive® Gearing may be subjected to a brief collision torque. The magnitude and frequency of this collision torque should be kept to a minimum and under no circumstances should the collision torque occur during the normal operating cycle.

Continuous stall current I_0 [A_{rms}]

Effective value of the motor phase current to produce the stall torque.

Continuous stall torque T_0 [Nm]

Allowable actuator stall torque.

Demagnetisation current I_E [A_{rms}]

Current at which rotor magnets start to demagnetise.

Dynamic axial load $F_{A\ dyn\ (max)}$ [N]

With bearing rotating this is the maximum allowable axial load, with no additional radial forces or tilting moments applied.

Dynamic load rating C [N]

Maximum dynamic load that can be absorbed by the output bearing before permanent damage may occur.

Dynamic radial load $F_{R\ dyn\ (max)}$ [N]

With bearing rotating this is the maximum allowable radial load, with no additional axial forces or tilting moments applied.

Dynamic tilting moment $M_{dyn\ (max)}$ [Nm]

With the bearing rotating this is the maximum allowable tilting moment, with no additional axial forces or radial forces applied.

Electrical time constant τ_e [s]

The electrical time constant is the time required for the current to reach 63% of its final value.

Hollow shaft diameter d_H [mm]

Free inner diameter of the continuous axial hollow shaft.


Inductance (L-L) L_{L-L} [mH]

Terminal inductance calculated without taking into account the magnetic saturation of the active motor parts.

Lost Motion (Harmonic Drive® Gearing) [arcmin]

Harmonic Drive® Gearing exhibits zero backlash in the teeth. Lost motion is the term used to characterise the torsional stiffness in the low torque region.

The illustration shows the angle of rotation ϕ measured against the applied output torque as a hysteresis curve, with the Wave Generator locked. The lost motion measurement of the gear is taken with an output torque of about $\pm 4\%$ of the rated torque.



Maximum DC bus voltage $U_{DC(max)}$ [VDC]

The maximum DC bus power supply for the correct operation of the actuator. This value may only be exceeded for a short period during the braking or deceleration phase.

Maximum hollow shaft diameter $d_{H(max)}$ [mm]

For gears with a hollow shaft, this value is the maximum diameter of the axial hollow shaft.

Maximum input speed (grease lubrication) $n_{in(max)}$ [rpm]

Maximum allowed input speed for gearing with grease lubrication.

Maximum input speed (oil lubrication) $n_{in(max)}$ [rpm]

Maximum allowed input speed for gearing with oil lubrication.

Maximum motor speed n_{max} [rpm]

The maximum allowable motor speed.

Maximum output speed n_{max} [rpm]

The maximum output speed. Due to heating issues, this may only be momentarily applied during the operating cycle. The maximum output speed can occur any number of times as long as the rated speed is greater than the permissible continuous operation calculated in the duty cycle.

Maximum output torque T_{max} [Nm]

Specifies the maximum allowable acceleration and deceleration torques. For highly dynamic processes, this is the maximum torque available for a short period. The maximum torque can be parameterized by the control unit where the maximum current can be limited. The maximum torque can be applied as often as desired, as long as the average torque is within the permissible continuous operation calculated in the duty cycle.

Maximum power P_{max} [W]

Maximum power output.

Mechanical time constant τ_m [s]

The mechanical time constant is the time required to reach 63% of its maximum rated speed in a no-load condition.

Momentary peak torque T_M [Nm]

In the event of an emergency stop or collision, the Harmonic Drive® Gearing may be subjected to a brief collision torque. The magnitude and frequency of this collision torque should be kept to a minimum and under no circumstances should the momentary peak torque occur during the normal operating cycle.

Moment of inertia J [kgm²]

Mass moment of inertia at motor side.

Moment of inertia J_{in} [kgm²]

Mass moment of inertia of the gearing with respect to the input.

Moment of inertia J_{out} [kgm²]

Mass moment of inertia with respect to the output.

Motor terminal voltage (Fundamental wave only) $U_M [V_{rms}]$

Required fundamental wave voltage to achieve the specified performance. Additional power losses can lead to restriction of the maximum achievable speed.

Number of pole pairs p

Number of magnetic pole pairs on the rotor of the motor.

Offset $R [mm]$

Distance between output bearing and contact point of load.

Pitch circle diameter $d_p [mm]$

Pitch circle diameter of the output bearing.

Protection IP

The degree of protection according to EN 60034-5 provides suitability for various environmental conditions.

Rated current $I_N [A]$

Rms value of the sinusoidal current when driven at rated torque and rated speed.

Rated motor speed $n_N [rpm]$

The motor speed which can be continuously maintained when driven at rated torque T_N , when mounted on a suitably dimensioned heat sink.

Rated power $P_N [W]$

Output power at rated speed and rated torque.

Rated speed $n_N [rpm]$

The output speed which can be continuously maintained when driven at rated torque T_N , when mounted on a suitably dimensioned heat sink.

Rated torque $T_N [Nm]$, Servo

The output torque which can be continuously transmitted when driven at rated input speed, when mounted on a suitably dimensioned heat sink.

Rated torque $T_N [Nm]$, Mechanic

The rated torque is a reference torque for the calculation of the gear life. When loaded with the rated torque and running at rated speed the gear will reach the average life L_{50} . The rated torque T_N is not used for the dimensioning of the gear.

Rated voltage $U_N [V_{rms}]$

Supply voltage for operation with rated torque and rated speed.


Ratio $i []$

The ratio is the reduction of input speed to the output speed.

Note for Harmonic Drive® transmission: The standard version of the wave is generating the drive element, the output element of the flexspline and the circular Spline is fixed to the housing. Since the direction of rotation of the drive (Wave Generator) to output reverses (Flexspline), a negative ratio for results Calculations in which the direction of rotation must be considered.

Repeatability [arcmin]

The repeatability of the gear describes the position difference measured during repeated movement to the same desired position from the same direction. The repeatability is defined as half the value of the maximum difference measured, preceded by a \pm sign.



Repeatable peak torque T_R [Nm]

Specifies the maximum allowable acceleration and braking torques. During the normal operating cycle the repeatable peak torque T_R should not be exceeded.

Resistance (L-L, 20° C) R_{L-L} [Ω]

Winding resistance measured between two conductors at a winding temperature of 20° C.

Size

1) Actuators / Gears with Harmonic Drive® gears or Harmonic Planetary gears

The frame size is derived from the pitch circle diameter of the gear teeth in inches multiplied by 10.

2) CHM Servo motor series

The size of the CHM servo motors is derived from the stall torque in Ncm.

3) Direct drives from the TorkDrive® series

The size of the TorkDrive® series is the outer diameter of theiron core of the stator.

Static load rating C_o [N]

Maximum static load that can be absorbed by the output bearing before permanent damage may occur.

Static tilting moment M_o [Nm]

With the bearing stationary this is the maximum allowable radial load, with no additional axial forces or tilting moments applied.

Tilting moment stiffness K_b [Nm/arcmin]

The tilting angle of the output bearing at an applied moment load.

Torque constant (motor) k_{TM} [Nm/A_{rms}]

Quotient of stall torque and stall current.


Torque constant (output) k_{Tout} [Nm/A_{rms}]

Quotient of stall torque and stall current, taking into account the transmission losses.

Torsional stiffness (Harmonic Drive® Gears) K_3 [Nm/rad]


The amount of elastic rotation at the output for a given torque and the Wave Generator blocked. The torsional stiffness K_3 describes the stiffness above a defined reference torque where the stiffness is almost linear. Values below this torque can be requested or found on our web site.

The value given for the torsional stiffness K_3 is an average that has been determined during numerous tests. The limit torques T_1 and T_2 and calculation example for the total torsional angle Gesamtverdrehwinkels can be found in the secondary technical documentation.




Torsional stiffness (Harmonic Planetary gears) K [Nm/rad]

The amount of elastic rotation at the output for a given torque and blocked input shaft. The torsional rigidity of the Harmonic Planetary gear describes the rotation of the gear above a reference torque of 15% of the rated torque. In this area the torsional stiffness is almost linear.



Transmission accuracy [arcmin]

The transmission accuracy of the gear represents a linearity error between input and output angle. The transmission accuracy is measured for one complete output revolution using a high resolution measurement system. The measurements are carried out without direction reversal. The transmission accuracy is defined as the sum of the maximum positive and negative differences between theoretical and actual output rotation angle.



Weight m [kg]

The weight specified in the catalog is the net weight without packing and only applies to standard versions.

6.2 Labelling, Guidelines and Regulations

CE-Marking

With the CE marking, the manufacturer or EU importer declares in accordance with EU regulation, that by affixing the CE mark the product meets the applicable requirements in the harmonization legislation established the Community.



REACH Regulation

REACH is a European Community Regulation on chemicals. REACH stands for Registration, Evaluation, Authorization and Restriction of Chemicals.



RoHS EU Directive

The RoHS EU Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment.



...just move it!



Deutschland
Harmonic Drive AG
Hoenbergstraße 14
65555 Limburg/Lahn

T +49 6431 5008-0
F +49 6431 5008-119

info@harmonicdrive.de
www.harmonicdrive.de



Subject to technical changes.